

**ENMET Corporation**  
**PO Box 979**  
**Ann Arbor, MI 48106-0979**

**AM-5150**  
**Ambient Air Monitor**  
**Manual**

**Manual part number**  
**80003-550**  
**MCN-409, 12/04/08**

## Table of Contents

<b>1.0 INTRODUCTION</b> .....	<b>1</b>
1.1 UNPACK.....	1
1.2 CHECK ORDER.....	1
1.3 SERIAL NUMBERS.....	1
<b>2.0 COMPONENTS OF THE AM-5150</b> .....	<b>2</b>
2.1 AM-5150 ELEMENTS.....	2
2.2 AM-5150 OPERATIONAL FEATURES.....	2
2.3 CIRCUIT BOARD FEATURES.....	3
<b>3.0 INSTALLATION OF THE AM-5150</b> .....	<b>4</b>
3.1 MOUNTING AM-5150.....	4
3.1.1 Wiring the AM-5150.....	5
3.1.2 Power Supply.....	5
3.2 SENSOR LOCATION.....	6
3.2.1 Sensor Hook-up.....	6
3.3 RELAY CONTACTS.....	7
<b>4.0 OPERATION</b> .....	<b>8</b>
4.1 START UP AM-5150.....	8
4.1.1 Typical Start Up.....	8
4.2 NORMAL DISPLAY MODE.....	9
4.2.1 Alarm Conditions AM-5150.....	9
<b>5.0 MAINTENANCE</b> .....	<b>10</b>
5.1 MAINTENANCE MENUS.....	10
5.2 CALIBRATION OF THE AM-5150.....	12
5.2.1 Exit Maintenance Menu.....	13
5.2.2 Zero Adjust.....	13
5.2.3 Gas Span.....	14
5.2.4 Alarm Set Points.....	15
5.2.5 mA Span Set.....	15
5.3 SENSOR REPLACEMENT.....	16
5.3.1 A Factory calibration must be performed.....	16
<b>6.0 ACCESSORY AND REPLACEMENT PARTS</b> .....	<b>17</b>
<b>7.0 TECHNICAL DATA AND SPECIFICATIONS</b> .....	<b>17</b>
<b>8.0 WARRANTY</b> .....	<b>18</b>

## List of Tables

<b>TABLE 1 : RELAY FAILSAFE SETTINGS</b> .....	<b>7</b>
<b>TABLE 2: AM-5150 MAINTENANCE MENUS SEQUENCE</b> .....	<b>10</b>

## List of Illustrations


<b>FIGURE 1: EXTERNAL AM-5150 FEATURES</b> .....	<b>2</b>
<b>FIGURE 2: AM-5150 CIRCUIT BOARD FEATURES</b> .....	<b>3</b>
<b>FIGURE 3: MOUNTING AM-5150</b> .....	<b>4</b>
<b>FIGURE 4: POWER TERMINAL CONNECTIONS AM-5150</b> .....	<b>5</b>
<b>FIGURE 5: RELAY TERMINAL CONNECTIONS AM-5150</b> .....	<b>7</b>
<b>FIGURE 6: AM-5150 MAINTENANCE MENU FLOW CHART</b> .....	<b>11</b>
<b>FIGURE 7: CALIBRATION ADAPTER</b> .....	<b>12</b>
<b>FIGURE 8: AM-5150 SENSOR REPLACEMENT</b> .....	<b>16</b>

Reference Information:

**NOTE:** [important information about use of instrument]

**CAUTION:** [affects equipment – if not followed may cause damage to instrument, sensor etc...]

**WARNING:** [affects personnel safety – if not followed may cause bodily injury or death.]

 Earth Ground

## 1.0 Introduction

The **AM-5150** is an ambient air monitoring instrument that measures and detects gases utilizing a non-specific MOS sensor. The **AM-5150** is *NOT* in an enclosure rated for use in a Class I, Div 1, Groups B, C, D classified area and **can not** be installed in a hazardous location. However, the remote sensor housing and sensor are rated for Class I, Div 1, Groups A, B, C & D hazardous locations and may be installed in such locations with appropriate wiring.

### Features of the **AM-5150**:

- continuous monitoring of the ambient air
- continuous LCD display of gas and vapor concentrations
- menu driven operational and maintenance controls
- menu driven calibration procedure
- audio and visual alarms indicate unsafe conditions
- alarm relay contacts available on terminals
- a fault relay and visual fault alarm
- alarm acknowledgement capability including audio defeat
- mA outputs for target gas

**NOTE:** *All specifications stated in this manual may change without notice.*

## 1.1 Unpack

Unpack the **AM-5150** and examine it for shipping damage. If such damage is observed, notify both **ENMET** customer service personnel and the commercial carrier involved immediately.

### Regarding Damaged Shipments

**NOTE: It is your responsibility to follow these instructions. If they are not followed, the carrier will not honor any claims for damage.**

- This shipment was carefully inspected, verified and properly packaged at our company and delivered to the carrier in good condition.
- When it was picked up by the carrier at **ENMET**, it legally became your company's property.
- If your shipment arrives damaged:
  - Keep the items, packing material, and carton "As Is." Within 5 days of receipt, notify the carrier's local office and request immediate inspection of the carton and the contents.
  - After the inspection and after you have received written acknowledgment of the damage from the carrier, contact **ENMET** Customer Service for return authorization and further instructions. Have your Purchase Order and Sales Order numbers available.
- ENMET** either repairs or replaces damaged equipment and invoices the carrier to the extent of the liability coverage, usually \$100.00. Repair or replacement charges above that value are your company's responsibility.
- The shipping company may offer optional insurance coverage. **ENMET** only insures shipments with the shipping company when asked to do so in writing by our customer. If you need your shipments insured, please forward a written request to **ENMET** Customer Service.

### Regarding Shortages

If there are any shortages or questions regarding this shipment, please notify **ENMET** Customer Service within 5 days of receipt at the following address:

**ENMET Corporation**  
680 Fairfield Court  
Ann Arbor, MI 48108  
734-761-1270 734-761-3220 Fax

## 1.2 Check Order

Check the contents of the shipment against the purchase order. Verify that the **AM-5150** is received as ordered. Each **AM-5150** is labeled with its target gas. If there are accessories on the order, ascertain that they are present. Check the contents of calibration kits. Notify **ENMET** customer service personnel of any discrepancy immediately.

## 1.3 Serial Numbers

Each **AM-5150** is serialized. These numbers are on tags on the equipment and are on record in an **ENMET** database.

## 2.0 Components of the AM-5150

### 2.1 AM-5150 elements

See Figure 1 for location of elements:


Feature	Description
<b>Enclosure</b>	A polycarbonate box, approximately 7 x 5 x 3, with a detachable front cover. 4 holes for mounting the enclosure to a vertical surface. Located at the corners of the bottom of the enclosure, directly beneath the 4 front cover retaining screws. See <b>Figure 3</b>
<b>Front Cover</b>	Detachable front cover of <b>AM-5150</b> with Display Panel. See <b>Section 2.2 and Figure 1</b> There are 4 Screws that hold the front cover in place.

### 2.2 AM-5150 Operational Features

The Display Panel is attached by a cable and is released by unscrewing the 4 screws located in the corners. After releasing the panel, it is swung upward, exposing the interior of the enclosure. See **Figure 1** for location of features.

Feature	Description
<b>Display</b>	A single line, 8 character LCD with backlight. Indicates the level of gas detected by sensor. The numerical value of gas concentration and other information is displayed.
<b>Audio Alarm(Horn)</b>	Audio alarm (105 dB at 30cm/12in). The audio alarm is activated when the unit is in alarm.
<b>Visual: Indicators and Alarms</b>	LED indicators: Power / Fault Indicator LED, Green / Red Alarm (3) Indicator LED, Red
<b>Membrane Switches</b>	2 Pushbutton Switches on front panel control the instrument maintenance functions. The pushbutton switch locations are indicated by: <b>MENU</b> ↓: Advances the instrument display through operation information and maintenance menus <b>SELECT</b> →: Disables audio alarm temporarily and Selects the maintenance menu operations such as, Zero, Span, Exit menu or sets proper calibration values for Zero or Span See <b>Section 4.0 and 5.0</b> for operational and maintenance flow charts.

Three alarm points are preprogrammed into the **AM-5150**. At each alarm point, an LED on the front panel is activated. There are 4, 10 Amp relay contacts at each alarm point, plus a fault relay. See Section 3.2 for wiring information.




**Figure 1: External AM-5150 Features**

### 2.3 Circuit Board Features

The Display Panel is attached by a cable and is released by unscrewing the 4 screws located in the corners. After releasing the panel, it is swung upward, exposing the interior of the enclosure. The Circuit Board is mounted at the back surface of the enclosure interior. Features are shown in **Figure 2**.

Feature	Description
<b>Relay Terminals: J14, J15, J16, J17</b>	This group of terminals is located on the Circuit Board. For the contacts for each of three alarm relays, and for the contacts of a fault relay. See <b>Section 3.3</b>
<b>Terminal J12</b>	For VDC back-up power in and the 4-20 mA output. See Section 3.1.2
<b>Sensor Terminal J8</b>	Sensor connection, See Section 3.2
<b>Data Terminal J19</b>	RS-485 input/output
<b>Potentiometer 4</b>	Sensor heater voltage adjustment, See Section 3.2.1
<b>Potentiometer 2 &amp; 3</b>	Not used in <b>AM-5150</b> Do Not Adjust



**Figure 2: AM-5150 Circuit Board Features**

### 3.0 Installation of the AM-5150


The **AM-5150** is supplied with a strain relief for a power line cord. Use this fitting or connect a conduit fitting when supplying power to the unit.

NOTE: This control panel is *NOT* rated for hazardous locations. The control panel must be located in a *NON*-Hazardous area.

#### 3.1 Mounting AM-5150

Mount the **AM-5150** instrument on an appropriate vertical surface, leaving room for lid to be opened, using the mounting holes provided. Avoid areas with excessive vibration or temperature extremes. The holes in the bottom of the enclosure are 0.18 inch in diameter and form a 6.44" x 4.47" rectangle. See **Figure 3**

It is recommended to use #8 drywall anchors and screws for mounting the **AM-5150** to a drywall/sheetrock surface.



Dimensions are in inches.

**Figure 3: Mounting AM-5150**

**3.1.1 Wiring the AM-5150**

The electrical installation should conform to appropriate electrical codes, such as the National Electrical Code in the United States.

**WARNING:** The compliance of the installation to appropriate codes is not **ENMET's** responsibility.

The **AM-5150** should be powered through circuit breakers provided for this purpose.

**3.1.2 Power Supply**

The input power can vary from 100 to 240 VAC, 50/60 Hz. Power should be connected to the Power Input Terminal **TB1** and the **Ground screw**. See **Figure 4** for location.

For DC wiring 24VDC may be wired to J12, (J12-1)position 1 + with ground connected to (J12-2)position 2.



Upon supplying power to the **AM-5150**:

- The green power on LED is lit.
- The display backlight is lit, and instrument will step through a start-up sequence: unit serial number and software revision may be shown on the display.

The instrument may go into alarm briefly, but the sensors stabilize quickly. If the instrument persists in alarm, acknowledge the alarm by pressing the **SELECT** button. If alarm persists longer than 30 minutes, call **ENMET** customer service personnel.

**WARNING:** Continuous gas detection and alarm systems (110VAC/220VAC / 24VDC/12VDC powered) become inoperative upon loss of primary power. Contact factory for specifications and pricing of backup battery systems.

**AC Power Supply Terminal: TB1**

	Label on PCB	Function
<b>110VAC</b>	TB1 ACN	Neutral
	TB1 ACL	Line
<b>Ground Screw</b>		AC GND
<b>220VAC</b>	TB1 ACN	Neutral
	TB1 ACL	Line
<b>Optional Ground Screw</b>		AC GND


**CAUTION:** 110/220 VAC when applied

**DC Power Supply/4-20mA Terminal: J12**

Position	Function
<b>1 +</b>	24 VDC power
<b>2</b>	GND
<b>3</b>	4 - 20 mA out

**Sensor Terminal: J8**

Position	Function	Color
<b>1</b>	Heater	Orange
<b>2</b>	Signal	Blue
<b>3</b>	Ground	2 wires, Brown & Yellow



**CAUTION:** 110/220 VAC when applied

**Figure 4: Power Terminal Connections AM-5150**

### 3.2 Sensor Location

Gases have different densities. Some are heavier than air and concentrate at the bottom of a space. Some are lighter than air and gather at the top. Consider the density of the gas you want the sensor to detect when you install the sensor. Some examples are given below.

Heavier than Air Gas	Sensor Location
Bottled LP (liquefied petroleum)	Interior wall; 18-24" from floor. ▪ DO NOT locate directly above or beside gas appliances (ovens, heaters). ▪ Avoid locating anywhere near a vent or window or near an outside doorway.
Propane	
Butane	
Gasoline	
Trichloroethylene	
Vaporized hydrocarbons	
Hydrogen sulfide	
Lighter than Air Gas	Sensor Location
Natural gas (methane)	Near ceiling. ▪ DO NOT locate directly above appliances where it is subject to direct exposure to heat or steam.
Ammonia	
Hydrogen	
Same Density as Air Gas	Sensor Location
Carbon Monoxide	4-6 feet above the (generally uniform) floor. ▪ DO NOT locate in direct air currents of windows, doors, or vents.


If you have a question involving the location of a unit or sensor, please contact your distributor or **ENMET** personnel. A technician will analyze the question and recommend a location.

#### 3.2.1 Sensor Hook-up

The MOS sensor is connected to the **AM-5150** control unit with four-conductor wiring, use the correct oil tight fitting. Two conductors supply heater current and ground for the sensor. The third and fourth conductors are signal wires. Size of the wire depends on the distance between the particular sensor and the control unit. See Recommended Wire Gauge Table below.

Sensor wires correspond to the normal wire code: orange – heater, brown – heater ground, blue – signal, yellow – signal

Internal View of Sensor Wiring



Wiring for Sensors

Position	Function	Wire Color
1	Signal	Blue
2	Heater	Orange
3	Heater Ground	Brown
Wire Nut	Signal	Yellow

NOTE: The user must perform the four color-coded wiring attachments when replacing the sensor. The yellow signal wire is not connected to the terminal block, use supplied wire nut.

\*Use position 2 and 3 to measure heater voltage. See heater voltage label for proper voltage. See Figure 3 for location of label.

#### Recommended Wire Gauge

Sensor Type	Distance from Sensor to Control Unit	Recommended Wire Gauge
High Voltage: 812, 813, 826, etc.	≤ 500 feet	16 AWG
	501 – 800 feet	14 AWG
	Longer Distances	Contact <b>ENMET</b> Corp
Low Voltage: 109	≤ 50 feet	16 AWG
	Longer Distances	Contact <b>ENMET</b> Corp

**CAUTION:** After you mount and install the **AM-5150** and Sensor, you must adjust the sensor heater voltage.

NOTE: Wire length between the **AM-5150** and the sensor greater than 100ft will require that the sensor heater voltage be reset. Locate the sensor heater voltage table inside the instrument, measure the sensor heater voltage at the sensor and adjust the heater adjustment POT 4 until required voltage reached. See **Figures 2 and 3**.

### 3.3 Relay Contacts

Relay contacts are available for each alarm; these are SPDT, rated at 10Amp at 110VAC, and may be latching or non-latching as required by the application.


They are accessed on the terminals next to each relay see **Figure 5**. The contact positions are noted on the circuit board next to each terminal.

The following table is for the relays in their un-energized state. This is also the alarm condition state. Non-failsafe configured relays in the alarm state, are the reverse of the PC board labeling. Note that the Fault(FLT) relay cannot be set to operate in a Non-Failsafe mode. Please see **Table 1** below:

**TABLE 1 : RELAY FAILSAFE SETTINGS**

Alarm	Position	
Alarm 1	J14 (K1)Relay 1 - NO	Normally Open
	J14 (K1)Relay 1 - NC	Normally Closed
	J14 (K1)Relay 1 - COM	Common
Alarm 2	J15 (K2)Relay 2 - NO	Normally Open
	J15 (K2)Relay 2 - NC	Normally Closed
	J15 (K2)Relay 2 - COM	Common
Alarm 3	J16 (K3)Relay 3 - NO	Normally Open
	J16 (K3)Relay 3 - NC	Normally Closed
	J16 (K3)Relay 3 - COM	Common
Fault Alarm	J17 (K4)Relay 4 - NO	Normally Open
	J17 (K4)Relay 4 - NC	Normally Closed
	J17 (K4)Relay 4 - COM	Common

These relay contacts can be used to operate auxiliary alarms or other functions. The relay contacts are DRY, power must be supplied. It is recommended that power for auxiliary equipment be supplied from an independent power source separate from the **AM-5150**. Use the existing hole in the enclosure for wire to enter and exit and use appropriate cable fittings. Wiring should be grouped together, VAC wires should be separated for VDC wires.



**Figure 5: Relay Terminal Connections AM-5150**

## 4.0 Operation

When the **AM-5150** is installed as described in **Section 3**, and in clean air, the POWER green LED is on, the display is lit and the information on the display is measurement of the target detected by the **AM-5150**. The red alarm and fault LEDs are not lit.












### 4.1 Start Up AM-5150

When the **AM-5150** is first powered up, it goes through a series of momentary screens, which identify the instrument model number, serial number and software revision. After all of the momentary screens have been displayed, the instrument arrives at the Main Gas Display showing the gas concentration and unit of measurement, ppm or %LEL.

Depending on transmitter configuration and calibration condition, the furthest right character in the display may flash a letter indicating the instrument status. See the Section 4.1.1 below

#### 4.1.1 Typical Start Up

When power is supplied to the **AM-5150**, the instrument will display the following sequence of information:  
Typical start up sequence of information displayed.

Example of Typical Start Up Display	Function
	The instrument: Model <b>AM-5150</b>
 <i>Example for reference only</i>	The instrument: Serial Number
 <i>Example for reference only</i>	The instrument: Software Revision
<b>IF</b> the right most character is a flashing <b>W</b> 	The instrument is in Warm-up mode <ul style="list-style-type: none"> <li>▪ This should last about 1 minute</li> <li>▪ The Signal Output is held at 4mA during warm-up</li> </ul>
<b>IF</b> the right most character is a flashing <b>C</b> 	The instrument has failed Calibration The last good calibration values are retained, but the sensor may not be responsive to gas A new Calibration should be performed <i>As Soon As Possible</i>
 OR 	The instrument: Normal Display Mode Measurement of the target gas
 ↔ 	The instrument: in Purge Mode Display <ul style="list-style-type: none"> <li>▪ <i>Optional feature</i>, not required in all instruments</li> </ul>
 ↔ 	The instrument: in Recovery Mode Display

NOTE: Software revision may cause variations of display output.

Prolonged storage of the **AM-5150-MOS** may result in some contamination of the sensor. Following start up, if the display reads above 000 a sensor purge function should be performed.

**Sensor Purge:** A sensor purge is performed to clean the MOS sensor (Metal Oxide Sensor) of molecules that may have settled on the sensor.

NOTE: Not all instruments are equipped with or require the Purge feature.

Press and **hold** the **SELECT** switch, 3 to 5 seconds, until 0ppP appears in the display. If the **AM-5150-MOS** is equipped with the purge feature, the display will alternate between 0ppm and 0ppP and the green Power/Fault LED will flash. In approximately 2 minutes the purge function will be completed and the display will, alternate between 0ppm and 0ppR indicating the instrument is in recovery mode. Recovery mode lasts approximately 5 minutes.

When the purge cycle is complete, the display will become stable at 0ppm and the green Power/Fault LED will stop flashing.


## 4.2 Normal Display Mode

When the **AM-5150** is installed as described in section 3, and in clean air, the **POWER** green LED is on, the display is lit and the information on the display in measurement units of ppm or %LEL detected by the **AM-5150**. The red alarm and fault LEDs are not lit.

To advance through displays of operational information press the **MENU** button.

**NOTE:** Software revision may cause variations of display output.

See sequence of operational information below:



Operational Display Flow Chart

### 4.2.1 Alarm Conditions AM-5150

There are three alarm set points available. These alarm points are normally set at established safety levels, such as the OSHA Permissible Exposure Limit (PEL) for toxic gases or recognized standards below the Lower Explosive Limit for combustible gases.

These alarm set points can be changed within limits; see the maintenance section of this manual for the procedure.

If the gas concentration increases above that of the alarm set point, the associated red LED is lit, the associated relay changes state, and the audio alarm is activated.

Pressing the **SELECT** button can temporarily disable the Audio Alarm. The horn will be disabled for about five minutes. If a second alarm condition occurs during this time the horn will re-activate. If the alarm condition(s) have ended during this time the horn will not re-activate.

## 5.0 Maintenance

The **AM-5150** maintenance menus that are accessed by pressing the **MENU** button and **SELECT** button as described in the maintenance menu section.

### 5.1 Maintenance Menus


**CAUTION:** Do Not Attempt A Span Procedure Without Calibration Gas Applied to The Sensor; if this is done, the instrument is forced into a calibration fault mode.

Pushbutton switches control the **MENU** and **SELECT** functions. The **MENU** and **SELECT** button locations are indicated on the display panel, see **Figure 1**. The **MENU** button is used to display the various menu options and make incremental changes to numbers such as alarm points, calibrations gas, etc. The **SELECT** button is used to select that option, set zero or span digit.


**NOTE:** Not all instruments are equipped with or require the Purge feature.

**Sensor Purge:** Prior to calibration the MOS(Metal Oxide Sensor) sensor should be purged. A sensor purge is preformed to clean the MOS sensor of molecules that may have settled on the sensor.

Press and **hold** the **SELECT** switch, 3 to 5 seconds, until 0ppP appears in the display. If the **AM-5150-MOS** is equipped with the purge feature, the display will alternate between 0ppm and 0ppP and the green Power/Fault LED will flash. *Example of purge display*



In approximately 2 minutes the purge function will be completed and the display will, alternate between 0ppm and 0ppR indicating the instrument is in recovery mode. Recovery mode lasts approximately 5 minutes.









When the purge cycle is complete, the display will become stable at 0ppm and the green Power/Fault LED will stop flashing.

To enter the maintenance menu press and **hold** the **MENU** button for 2 to 4 seconds

**Table 2** indicates the maintenance menu sequence see **Figure 6** for a detailed maintenance menu flow chart.

**NOTE:** Software revision may cause variations of display output.

**TABLE 2: AM-5150 MAINTENANCE MENUS SEQUENCE**

Example of Display	Function
Normal Display Mode 	Measurement of CO
Press and <b>hold</b> the <b>MENU</b> button for 2 – 4 seconds to enter the Maintenance Menu The Power/Fault LED will flash Green – Red to indicate the <b>AM-5150</b> is in Maintenance Mode	
	To exit the maintenance Menu and return to the Normal Display Mode: If intended function Press <b>SELECT</b> button
Press the <b>MENU</b> button to advance to the Zero procedure	
	For adjusting Zero: If intended function Press <b>SELECT</b> button
Press the <b>MENU</b> button to advance to the Span procedure	
	For adjusting the Span: If intended function Press <b>SELECT</b> button
Press the <b>MENU</b> button to advance to each Alarm set point procedures	
	For adjusting the Alarm 1, 2 and 3 set points: If Intended function Press <b>SELECT</b> button
Press the <b>MENU</b> button to advance the mA Span set point procedure	
	For adjusting the mA Span set point: If intended function Press <b>SELECT</b> button

Pressing the **MENU** button without pressing the **SELECT** button will allow you to cycle through the menu options. You must Press the **SELECT** button in order to initiate the desired operation.

NOTE: Software revision may cause variations of display output.

Normal Gas Display




FIGURE 6: AM-5150 Maintenance Menu Flow Chart

## 5.2 Calibration of the AM-5150

Calibration is the process of setting the instrument up to read accurately when exposed to the target gas. The Zero function sets the clean air reference point and the Span function sets the sensitivity of the instrument.

**Initial Calibration:** Wait at least 3 – 4 hours after initially supplying power to the **AM-5150** instrument before initial calibration, overnight is preferred. The **AM-5150** has been pre-calibrated at the factory, and initial field calibration should result in only fine-tuning to circuit, as well as a way to check that installation is successful. It is not necessary to open the enclosure to make adjustment. The calibration functions are operated with pushbuttons from outside the enclosure through the **MENU** and **SELECT** switches.

Calibration Zero and Span functions are two separate procedures. They operate independently of each other. It is recommended that the Zero procedure be done prior to the Span procedure.


*ENMET Corporation recommends at least quarterly calibration of the **AM-5150** instrument.*

Calibration equipment is available from **ENMET** Corporation to calibrate the **AM-5150** instrument.

- Calibration adapter, a length of tubing with a regulator for the gas cylinder on one end, and a calibration cup to connect to the sensor of the **AM-5150** on the other.
- Gas cylinder, Zero gas 20.9% oxygen or Span gas, factory determined, varies by intent.

Generally, a cylinder of 20.9% Oxygen is used to provide a Zero point or fresh air reference for the calibration.

**NOTE:** Software revision may cause variations of display output.




**Figure 7: Calibration Adapter**

### 5.2.1 Exit Maintenance Menu

Exit maintenance, by pressing the Exit appears on the display. Press the **SELECT** button to return to the instrument Normal Gas Display.

Example of Exit menu:



### 5.2.2 Zero Adjust

The ZERO function must be performed by exposing the **AM-5150** instrument to clean fresh air. If the air at the sensor is in question, use a cylinder of 20.9% oxygen to provide a clean air reference.

Enter the maintenance menu by pressing and holding **MENU** button for 2 to 4 seconds. See **Figure 6, AM-5150** Maintenance Menu flow chart.

After entering the maintenance menu, Press the **MENU** button until the Zero menu is displayed.


Press the **SELECT** button to perform a Zero.

The display will alternate between Zero and PV: To abort Zero function press and hold **MENU** button for 3 – 4 seconds, Abort? will appear, press **SELECT** button to return to Zero.


Press the **SELECT** button to initiate a Zero adjustment.

An auto detect sequence is initiated. After 15 seconds, the **AM-5150** will monitor the zero reading for stability.

- *If the reading stabilizes*, within the pre-programmed perimeters, an automatic zero adjustment will be made. Cal OK appears on the display and in 1 – 2 seconds, display will change to Span. If you wish to Span the sensor press the **SELECT** button you are now ready to apply gas. **Proceed to gas span step 2**  
If you wish to Exit the maintenance menu, press **MENU** button until Exit is displayed, then press **SELECT** button to return to the instrument Normal Gas Display
- *If the reading does not stabilize*, within 255 seconds, the procedure will be aborted. Sensor is outside of safe parameters to be zeroed, the display will read Bad Zero. Repeat Section 5.2.2 Zero Adjust making sure to use a Zero gas of 20.9% Oxygen. **ENMET** part number 03296-209.



Example of Zero adjustment display:



NOTE: Software revision may cause variations of display output.

### 5.2.3 Gas Span

*It is recommended that the Zero Function be performed first.*

Do not perform a calibration unless span gas is applied to sensor. Calibration can be aborted by pressing and holding the **MENU** button for 3 – 4 seconds.

Enter the maintenance menu. See **Figure 6, AM-5150** Maintenance Menu flow chart.

1. Press the **MENU** button until Span display.
2. Press the **SELECT** button to perform a Span procedure.  
The display will alternate between the calibration gas concentration (*Example*: Cal 20) and a signal level (PV).
  - To Abort calibration press and Hold **MENU** button for 3 – 4 seconds, “Abort?” will appear, press **SELECT** button to return to Span.

**NOTE:** To abort calibration. Press and **HOLD** the **MENU** button to abort Calibration

When “Abort?” appears press **SELECT** button to advance to desired menu

- To change calibration gas level to be used, press and Hold **SELECT** button for 3 – 4 seconds, use menu button to change digit and select button to move to next digit.

**NOTE:** To change calibration gas level. Press and **HOLD** the **SELECT** button to change the Calibration Gas Level

- Use the **MENU** button to change digits
- Use the **SELECT** button to move to next digit

3. Attach the associated calibration gas cylinder to the calibration adapter. See **Figure 7** calibration adapter.
4. Open the valve to apply the calibration gas to the sensor.  
An auto detect sequence is initiated after 30 seconds, the **AM-5150** will monitor the cal reading for stability.
5. Watch for the signal level to stabilize. This should take about 1 – 4 minutes.
6. Once the signal level has stabilized,
  - If the Span is successful, Cal OK appears momentarily, then will advance to Alarm1 menu.  
To exit cal, press **MENU** button until Exit appears and press **SELECT** button
  - If the sensor is outside of acceptable parameters, Bad Span is displayed.
  - If the sensor did not respond, an incompatible span gas was applied and the sensor did not respond at all, Same mV is displayed then will return to Span.
  - ➔ If calibration is not successful, it is suggested that calibration be attempted again in 30-60 minutes.  
If the sensor will not calibrate *See Section 5.3* for sensor replacement.
7. Remove the calibration gas.
8. Press the **MENU** button to advance to Exit menu or desired menu.

NOTE: Software revision may cause variations of display output.

*Example of Calibration Display:*

**Apply** Cal Gas until signal value becomes stable  
(about 1 to 4 minutes) See **Figure 7** Calibration Adapter

When cal signal is stable **AM-5150** will automatically update:  
**If** cal is good display will indicate OK or Same and advance to Alarm1

**If** cal is not within preset “range” display will indicate Bad Sens or Same mV The **AM-5150** will return to the Span Menu

OR

To exit press **MENU** button until Exit appears and press **SELECT**

### 5.2.4 Alarm Set Points

The **AM-5150** has three alarm set points set at the factory. These alarm points are normally set at established safety levels. Alarm set points can be changed within limits.


To change any of the three alarm points:

Enter the maintenance menu as shown in **Figure 6 AM-5150** Maintenance Menu flow chart.

1. Press the **MENU** button until to display Alarm1 is displayed.
2. Press the **SELECT** button to initiate alarm set point change
3. Press the **MENU** button to change the digit indicated by the underscore cursor
4. Press the **SELECT** button to move the cursor to the next digit  
When last digit is entered the **AM-5150** will advance to the next menu
5. Press the **MENU** button to advance to the next menu

NOTE: Alarms 2 and 3 can not be set below the Alarm 1 setting.

Example of Alarm Set Point menus:



To change Alarm set points:  
 Press Menu button until Alarm to be changed is displayed  
 Press Select button to display the set point  
 The **MENU** button changes digit indicated by underscore cursor  
 The **SELECT** button locks underscored digit and moves to next digit  
**If** change is not within range display returns to previous digit  
**If** change is within range display moves to next menu

NOTE: Software revision may cause variations of display output.

### 5.2.5 mA Span Set


The **AM-5150** 4-20mA span range is set at the factory, normally to the full scale of the measurement and can be changed within limits.

To change the span range:

Enter the maintenance menu as shown in **Figure 6 AM-5150** Maintenance Menu flow chart.

1. Press the **MENU** button until to display Span is displayed.
2. Press the **SELECT** button to initiate the mA Span menu
3. Press the **MENU** button to change the digit indicated by the underscore cursor
4. Press the **SELECT** button to move the cursor to the next digit  
When last digit is entered the **AM-5150** will advance to the next menu
5. Press the **MENU** button to advance to the next menu

Example of mA Span menu:



To change mA Span set points:  
 Press Menu button until mA Span is displayed  
 Press Select button to display the set point  
 The **MENU** button changes digit indicated by underscore cursor  
 The **SELECT** button locks underscored digit and moves to next digit

Default mA Span

4mA	20mA
0 ppm	200 ppm

## 5.3 Sensor Replacement

**WARNING:** Power must be removed from the AM-5150 before this or any internal procedure. Failure to do so may cause damage to equipment, bodily injury or death.


The MOS sensor is durable, it can be purged of contaminants by operating in PURGE for a sufficient length of time and at regular intervals.

Gross contamination usually occurs during unavoidable misuse. Close exposure to an open gas flame, submersion of the sensor in a liquid, or continuous exposure to heavy concentrations of industrial vapors will grossly contaminate a sensor. A grossly contaminated sensor causes a continuous alarm.

If a sensor fails to calibrate, replace it.

### PROCEDURE:

1. Obtain a new sensor assembly. Make sure the sensor type is identical to your original sensor  
Sensor marking is on side of sensor see Figure 8(Example: 813-4 the first 3 digits are sensor ID the 4 digit indicates a 4-wire sensor).
2. Disconnect the instrument for power.
3. Disconnect the orange, brown and blue sensor wires.
4. Unscrew the assembly from the sensor enclosure.
5. Remove the bad sensor.
6. Replace with the new sensor and reconnect the wires (See Section 3.2.1).  
NOTE: The user must perform the four color-coded wiring attachments when replacing the sensor. The yellow signal wire is not connected to the terminal block, use supplied wire nut.  
\*NOTE the correct direction the spacer ring must be placed.
7. Reconnect the instrument to power and verify sensor heater voltage. (See Section 3.2.1)
8. Recalibrate the instrument (See Section 5.2).



**Figure 8: AM-5150 Sensor Replacement**

After the new sensor assembly has been installed, it is suggested to allow the sensor to stabilize for at least 3 – 4 hours, preferably over night.

### 5.3.1 A Factory calibration must be performed.

After entering the Maintenance menu, press and hold the **MENU** button for 2-4 seconds while viewing the Zero menu.

After 2-4 seconds, an F will appear on the far right hand side of the display. The F indicates that the instrument is in Factory mode.

Perform the calibration Zero and Span procedures as outlined in **Section 5.2**. Be sure that the F is present when selecting the Zero and Span functions.

The Factory calibration sets a calibration window for future standard instrument calibrations.

## 6.0 Accessory and Replacement Parts

ENMET accessory part numbers:

Description of Part	Part Number
Sensor Marking, 109-4	03034-109
Sensor Marking, 812-4	03034-812
Sensor Marking, 813-4	03034-813
Sensor Marking, 018-4	03034-018
Sensor Marking, 019-4	03034-019
Sensor Marking, 821-4	03034-821
Sensor Marking, 830-4	03034-830
Sensor Marking, 832-4	03034-832
Zero Gas, 20.9% O <sub>2</sub> , 17 liter	03296-209
Span Gas	
Cylinder of Calibration Gas	Contact <b>ENMET</b> for part number of target gas for each instrument. See note below.

NOTE: The gases should be identical, or equivalent (correlation gas) to those used to initially calibrate the unit, unless you want to recalibrate to a new gas or different concentration. In addition, calibration gases must be in a background of air; do not use gases with an inert gas background (such as nitrogen or argon).

ENMET replacement part numbers:

Description of Part	Part Number
Horn	62013-007

## 7.0 Technical Data and Specifications

<b>Electrical Power</b>	15 Amp fused branch circuit	
	100-240 VAC	
	0.45A, 50/60 Hz	
	0.6A, 24VDC	
<b>Storage and Transport</b>	Temperature:	-20° to +60°C (-4° to +140°F)
	<i>preferred</i>	0° to +20°C (32° to 68°F)
	Relative Humidity	10-99% RH, non-condensing
	Atmospheric Pressure	20 to 36 inHg (68 to 133 kPa)
<b>Operation</b>	Temperature:	-15° to +40°C (5° to +104°F)
	Relative Humidity	10-99% RH, non-condensing
	Atmospheric Pressure	20 to 36 inHg (68 to 133 kPa)
<b>Mechanical</b>	Dimensions:	7.1 x 5.1 x 3 in(180x130x75mm)
	Weight:	2 lbs (0.9 kg)
	Material:	Polycarbonate
	Strain relief:	3-6.5mm OD
<b>Outputs</b>	Relays:	SPDT Resistive Load    Inductive Load 10A at 110 VAC    7.5A at 110 VAC 10A at 30 Vdc    5A at 30 Vdc
	Analog:	4-20mA
	Digital:	RS-485-modbus
	Audio:	105 dB at 30cm/12in

NOTE: All specifications stated in this manual may change without notice.

## 8.0 WARRANTY

**ENMET** warrants new instruments to be free from defects in workmanship and material under normal use for a period of one year from date of shipment from **ENMET**. The warranty covers both parts and labor excluding instrument calibration and expendable parts such as calibration gas, filters, batteries, etc... Equipment believed to be defective should be returned to **ENMET** within the warranty period (transportation prepaid) for inspection. If the evaluation by **ENMET** confirms that the product is defective, it will be repaired or replaced at no charge, within the stated limitations, and returned prepaid to any location in the United States by the most economical means, e.g. Surface UPS/FedEx Ground. If an expedient means of transportation is requested during the warranty period, the customer is responsible for the difference between the most economical means and the expedient mode. **ENMET** shall not be liable for any loss or damage caused by the improper use of the product. The purchaser indemnifies and saves harmless the company with respect to any loss or damages that may arise through the use by the purchaser or others of this equipment.

This warranty is expressly given in lieu of all other warranties, either expressed or implied, including that of merchantability, and all other obligations or liabilities of **ENMET** that may arise in connection with this equipment. **ENMET** neither assumes nor authorizes any representative or other person to assume for it any obligation or liability other than that, which is set forth herein.

NOTE: When returning an instrument to the factory for service:

- Be sure to include paperwork.
- A purchase order, return address and telephone number will assist in the expedient repair and return of your unit.
- Include any specific instructions.
- For warranty service, include date of purchase
- If you require an estimate, please contact **ENMET** Corporation.

There are Return for Repair Instructions and Form on the last pages of this manual. This Form can be copied or used as needed.

Manual part number  
80003-550

November 2006

MCN-367, 05/17/07

MCN-372, 06/18/07

MCN-385, 10/22/07

MCN-409, 12/04/08



PO Box 979  
680 Fairfield Court  
Ann Arbor, Michigan 48106-0979  
734.761.1270 Fax 734.761.3220

# Returning an Instrument for Repair

**ENMET** instruments may be returned to the factory or any one of our Field Service Centers for regular repair service or calibration. The **ENMET** Repair Department and Field Service Centers also perform warranty service work.

When returning an instrument to the factory or service center for service, paperwork must be included which contains the following information:

- A purchase order number or reference number.
- A contact name with return address, telephone and fax numbers
- Specific instructions regarding desired service or description of the problems being encountered.
- Date of original purchase and copy of packing slip or invoice for warranty consideration.
- If a price estimate is required, please note it accordingly *and be sure to include a fax number.*

Providing the above information assists in the expedient repair and return of your unit.

**Failure to provide this information can result in processing delays.**

**ENMET** charges a one hour minimum billing for all approved repairs with additional time billed to the closest tenth of an hour. All instruments sent to **ENMET** are subject to a minimum evaluation fee, even if returned unrepared. Unclaimed instruments that **ENMET** has received without appropriate paperwork or attempts to advise repair costs that have been unanswered, after a period of 60 days, may be disposed of or returned unrepared COD with the evaluation fee.

Service centers may have different rates or terms. Be sure to contact them for this information.

**Repaired instruments are returned by UPS/FedEx Ground and are not insured unless otherwise specified. If expedited shipping methods or insurance is required, it must be stated in your paperwork.**

**Note:** Warranty of customer installed components.

If a component is purchased and installed in the field, and fails within the warranty term, it can be returned to **ENMET** and will be replaced, free of charge, per **ENMET's** returned goods procedure.

If the entire instrument is returned to **ENMET** Corporation with the defective item installed, the item will be replaced at no cost, but the instrument will be subject to labor charges at half of the standard rate.



# Repair Return Form

Mailing Address:  
ENMET Corporation  
PO Box 979  
Ann Arbor, Michigan 48106

Shipping Address:  
ENMET Corporation  
Attn: Repair Department  
680 Fairfield Court  
Ann Arbor, Michigan 48108

Phone Number: 734.761.1270  
FAX Number: 734.761.3220

Your Mailing Address:

Your Shipping Address:

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Contact Name: \_\_\_\_\_ Your Phone: \_\_\_\_\_

Your PO/Reference Number: \_\_\_\_\_ Your FAX: \_\_\_\_\_

Payment Terms:  COD

(Check one)  **VISA / MasterCard** \_\_\_\_\_  
Card number Expiration Card Code  
 **American Express** \_\_\_\_\_  
Card number Expiration Card Code

*Name as it appears on the credit card* \_\_\_\_\_

Return Shipping Method:

UPS:  Ground  3 Day Select  Next Day Air  ND Air Saver  2-Day Air  
 UPS Account number: \_\_\_\_\_

Federal Express:  Ground  Express Saver  P-1  Standard  2-Day Air  
 FedEx Account number: \_\_\_\_\_

Would you like ENMET to insure the return shipment?

No  Yes Insurance Amount: \$ \_\_\_\_\_